

How to Use Span-O Lube Marine Oil in Your System

Step-by-Step Guide

1. Check Compatibility

Ensure the oil grade matches your marine engine and equipment specifications.

2. Prepare the System

Drain any old oil and clean the system to prevent contamination.

3. Refill with Marine Oil

Pour the recommended Span-O Lube Marine Oil into the engine or equipment.

4. Start and Circulate

Run the engine to allow the oil to lubricate all moving parts properly.

5. Monitor Performance

Check for proper lubrication, temperature control, and smooth operation.

6. Regular Maintenance

Change oil at recommended intervals to maintain engine efficiency and longevity.

Maintenance Tips

Oil Change: Replace at regular intervals based on usage and manufacturer guidelines.

Regular Inspections: Monitor oil level and condition for optimal performance.

Warning Signs: Watch for excessive smoke, overheating, or unusual noises.

Proper Disposal: Follow environmental regulations for safe oil disposal.

Benefits of Span-O Lube Marine Oil

Superior lubrication for marine engines

Enhanced heat resistance

Extended engine life

Excellent detergency & cleanliness

Optimized fuel efficiency

Corrosion & wear protection